

AIRSAFE HITCH SYSTEM

LIMITED 2 YEAR WARRANTY

The AIRSAFE Fifth Wheel Hitch System is warranted against defects in material and workmanship under normal use and service, ordinary wear and tear excepted, for 2 years from the first date of purchase at retail. Any part found to have a defect in material or workmanship, will be repaired or replaced at the manufacturer's option when returned with transportation charges prepaid. Include a copy of the original sales receipt when returned for warranty. This warranty does not cover the condition, durability or appearance of the finished product.

If the hitch is damaged as a result of improper installation, alteration, vehicle accident, misuse of unreasonable use, including but not limited to, loading the product beyond the factory rated load capacity, the manufacturer shall not be required to repair or replace such product. In every case, this warranty covers only the defective part and does not provide for reimbursement of the retail price of the part or labor charges.

The manufacturer shall not be liable for any incidental or consequential damages for breach of any express or implied warranty.

There are no warranties that extend beyond the description on the face hereof. The manufacturer is extending no other warranties, express or implied, nor any warranties of merchantability or fitness for a particular purpose. Any such warranties of merchantability or fitness for a particular purpose are expressly excluded.

This warranty is designed and intended to fully comply with the requirements of the Magnusson-Moss Warrant Act and all regulations issued by the federal trade Commission in connection therewith. It is not intended to violate any state law or regulation containing more stringent requirements, and such requirements automatically become part of this warranty insofar as required by that act.

The owner has available the legal remedies provided by the Magnusson-Moss Warranty Act, Public Law 93-637, 99 STAT. 2183-2193; 15 U.S. Code, Secs 23021-2312, and any applicable state statutes.

For warranty assistance, contact Air Hitch Technology at:

1-866-41-HITCH (1-866-414-4824)

weekdays 8:00 AM to 5:00 PM (Central).

THE **REVOLUTION**
Next Generation

AIRSAFE 18K
HITCH SYSTEM

Installation Instructions
And
User Guide

6

Safety and Cautions

- Safety is of paramount importance in both installation and use of the Revolution AIRSAFE Hitch System. Observe all *Cautions* and *Notes* found in this manual, as well as common sense precautions to ensure the safety of yourself and others.
- The AIRSAFE Hitch is recommended for use only in regular size truck beds unless used in conjunctions with a hitch extender system for shorter bed trucks.
- The AIRSAFE Fifth Wheel Hitch System is designed to tow 5th Wheel Trailers with a Gross Vehicle Weight Rating not to exceed 18,000 lbs pin weight should not exceed 4,000lbs. Exceeding the rated capacity is not recommended.
- The Airbox is to be used only with the Hitch Head it is designed and sold for.
- Install the AIRSAFE Fifth Wheel Hitch System using bedrails that are rated for the Gross Vehicle Weight Rating of the Hitch Head (provided with hitch)
- **Caution:** On all installations, there must be a minimum of 5-1/2" clearance between the bottom of the trailer nose and the top of the truck bed/sides prior to inflation of the airbags. This is to prevent damage to the truck, trailer or hitch due to lack of clearance.
- **Caution:** Never inflate the Airbox airbags over 100 psi without contacting Air Hitch Technology first

Unpacking and Installation

1. **Unpacking:** The AIRSAFE Hitch comes completely assembled and bolted onto a pallet. Ensure all parts below are present..

H-245 Bedrails (Qty 2)
 Airbox (Qty 1)
 AB-X-502W Side Risers (Qty 2)
 18K Hitch Head

2. **Hitch Handle Assembly**

No assembly required

3. **Hitch/Rail Assembly**

Place the H-245 bedrails in the bed of the truck approximately 22" from each other. This should already be done on the pallet but ensure the distance is correct